


# HEATSINK HOLDER INSERTER

## Instruction Manual

< Lay-Out >



“Translation of the original instructions”

Company : HNP Technology Co., LTD.

Address : Seowon Techno Valley 408, suchuldaelo 152,  
Gumi-si, Gyeongsangbuk-do

Tel. : +82-54-464-2911~3

E-mail : info@hnpro.com

# Index

## Mechanism Manual

1. Safety Instructions
2. Equipment Maintenance
3. Outline
  - 3-1. Equipment Name
  - 3-2. Equipment Outline
  - 3-3. Apply MODEL
  - 3-4. Equipment Lay - out
4. Equipment Specifications
  - 4-1. Equipment Size
  - 4-2. Equipment Ability
  - 4-3. UTILITY
  - 4-4. Equipment Installation Use Environment
5. Basic Equipment Specifications
  - 5-1. FRAME UNIT
  - 5-2. INPUT CONVEYOR UNIT
  - 5-3. TRANSFER UNIT
  - 5-4. REVERSE UNIT
  - 5-5. HOLDER SUPPLY UNIT
  - 5-6. HOLDER INSERTER UNIT
  - 5-7. RETURN CONVEYOR UNIT
  - 5-8. OUTPUT CONVEYOR UNIT
6. Mechanism Drawing
  - 6-1. Assembly Drawing
  - 6-2. Consumable Parts
7. Pneumatic Circuit Diagram
8. Purchasing Item List
9. Parts Catalog [ Attached ]

# 1. Safety Instructions

## Chapter 1 Safety

### 1.1 Before start

This chapter describes items related to safety preparation for maintenance procedures and preventive maintenance. Users should follow all safety notices (precautions).



Various hazards exist around facilities such as electrical and mechanical hazards. Machine operators should be familiar with the following hazard symbols and how to respond to them.

Machine operators must be sufficiently familiar with preventive measures and countermeasures for each type of risk.

Response measures are designed to minimize or eliminate hazards to maintenance technicians and process workers, as well as to all machine operators working in close proximity to the system.

#### 1.1.1 Machine operator safety

- You may face serious danger if it is not assembled or operated in the correct way.
- The person who operates the equipment must be properly trained.
- Equipment may cause damage (damage) during automatic operation.
- It is very dangerous for a person with little knowledge of the system or a lack of understanding of the machine to operate the system inappropriately or carelessly.
- When working around equipment, be aware of the sharp edges of the system.

#### 1.1.2 Before work

- The person who operates this system must read this manual carefully and be familiar with its contents.
- Heed the statements under the headings "Danger", "Warning" and "Caution", and make sure you fully understand them.
- By following the user's manual, you can avoid risks during machine operation or maintenance.
- Before operating or servicing the system, be sure to read and understand the safety precautions in the manual and follow the warning labels throughout the system and the user manual. Failure to do so may result in personal injury or disaster and may result in damage to systems, products and facilities.
- Safety precautions can also be found in other areas.

### 1.1.3 Warning sign

- Warning signs are very important. Do not intentionally damage it.
- If it is damaged beyond readability (lost or accidentally damaged), a new tag must be placed in its place.

### 1.2 Warning of danger

During commissioning (installation or servicing of the system), attention should be paid to the following three levels of alertness. You must understand the contents and drive properly.

Warning statements are indicated in warning signs on the system and safety precautions in this manual.



"**DANGER**" Signs indicate specific anticipated hazards, such as serious injury or personal injury, when machine operators do not strictly follow the training instructions for hazards.

They are similar to warning statements, but are generally more dangerous.





"**WARNING**" Signs indicate specific anticipated hazards, such as serious injury or personal injury, when machine operators do not strictly follow the training instructions for hazards.




"**CAUTION**" Signs indicate hazards that may result in minor personal injury or damage to systems, products and facilities if machine operators do not strictly follow the hazard training instructions.

### 1.3 Safety sign

Table 1. Marker Description	
 <b>DANGER</b>	<p>&lt;Danger of high-voltage electric shock&gt;</p> <p>Contact with energized parts can burn or kill the operator's fingers.</p> <p>Power must be turned off before operating or servicing the system.</p>
 <b>WARNING</b>	<p>&lt;Danger of getting your hands rolled up and crushed&gt;</p> <p>It can get caught in moving parts.</p> <p>Do not operate without safety devices.</p>



 <p><b>CAUTION</b></p>	<p>&lt;general warning&gt;</p> <p>When information about a particular danger or escape cannot be explained by an effective symbol,</p> <p>Exclamation mark can express certain information in text.</p>
---	---

## 1.4 Main hazard and safety rules

### 1.4.1 Electrical hazard

This step is about current in system control.

If an operator accidentally touches a live or conductive part while servicing, he or she may be seriously injured or killed.

Before operating or servicing the machine, you must read this section to understand electrical hazards and precautions.

There is a possibility of electric shock when the system is still running.

#### Hazard of high-voltage electric shock

It is very dangerous to turn on the power without prior notice to the workers. Never turn on the power suddenly.



Careless power supply may injure or kill workers due to automatic operation or electric shock.

Warn other operators and do not allow outsiders to turn on the power. The main power is single phase 220V.

The main switchboard supplies power.

## **Safety rules**

When it comes to power cut and emergency shut off, this system is designed and built according to the standard of power and emergency shut off.

Generally, interlocks are fitted to minimize electrical hazards. Note: The cover must not be removed when servicing the system.

## **Operating Procedures and Precautions**

In locations where the prescribed hazards have not been eliminated, the following operating procedures and precautions must be followed to reduce or eliminate the potential for exposure of workers to hazards and to ensure safety and preventive measures.

### **General procedure for AC power**

Always remove power lines first when trying to remove electronics.

Conversely, when going to install electronics, install power lines last. Do not operate the system when the cover is not installed on the electronics.

Always turn off the main power when installing or removing electrical components. To prepare for sudden overcurrent phenomenon, it must be installed according to legitimate standards.

### **1.4.2 Mechanical hazard**

Plates are transported automatically during normal operation of the system, so no operator is required to enter the automated section.

However, when servicing, someone needs to enter the automation zone to make adjustments, etc.

Before servicing, you must read this section to understand mechanical hazards and precautions.

The system also contains assemblies containing moving parts that do not meet safety standards and may cause personal injury.



Do not restart automatic feed from a stopped state or start operation without permission from an operator near the automated machine.

Failure to do so will result in conflict between the automated machine and the operator.

## Hazard of crushing hands



- If the operator touches the automatic system even a little, his clothes, hat or hair get caught between the chains or in the automatically actuated zone in the operating section or driving section, resulting in strain, crush, laceration or broken bones. You may get injured.
- Do not put your arm or hand inside the transport unit when the cover is open.
- Workers in any area can be injured by moving parts. The relevant assemblies and areas are.
- Top of machine with interlock door.
- The lower part of the locked machine.

## Safety rules

The top of the machine is equipped with an extremely safe interlock that cuts off power to the moving parts when the door is opened.

The interlock door will not function when in manual mode.

You can operate the transport in manual mode while the top door is open.

In this state, the transfer unit can perform commands such as forward/backward movement, up/down movement, and rotation.

Therefore, hands and fingers may be injured if the conveyor is operating.

The user's manual contains warnings that can prevent danger.

The inside of the bottom of the machine (locked with a cover that needs to be opened and closed) must be kept clean.

When doing so, care must be taken not to get your hands or fingers caught in the rotating belt, which could injure your hands or fingers.

## Operating Procedures and Precautions

In locations where prescribed hazards have not been eliminated, the following precautions must be followed to reduce or eliminate the possibility of exposure of workers to hazards and to ensure safety and preventive measures.

## Operating Procedures and Precautions

In locations where prescribed hazards have not been eliminated, the following operating procedures are designed to reduce or eliminate the potential for temporary exposure of personnel to hazards and to ensure safety maintenance and precautions.

The technical instruction manual contains warnings in case of danger.

### 1.5 Safety signs

- Safety signs must convey information about specific hazards.
- Safety signs should be simple, direct and understandable to viewers.
- What the safety sign convey.
  - Significant hazard (indicated by signal words)
  - the nature of the hazard (e.g. type of risk) or expected consequences of the hazard
  - How to avoid hazard

#### 1.5.1 Safety signs and their location

< Reference 1 > Hazard of getting your hands rolled in



< Reference 2 > Hazard of electric shock



< Reference 3> INTER-LOCK DOOR



## 1.6 Cover

When carrying out maintenance work, the main switch must be turned off.

At this time, the main switch must be locked so that other workers cannot touch it.

Besides, signs are installed to alert other operators. This is a cover.

In this equipment, it is necessary to attach a minimum number of markings to the following parts.

- **Main switch**

Furthermore, when carrying out maintenance work within the work area or loading area, it is also necessary to place signs on the other side of the (front) machine.

## 1.7 Emergency Stop

### 1.7.1 Main emergency stop



In the case of an emergency stop with an emergency switch, the operation of the equipment is stopped.

As long as the power on the factory side is not turned off, the power is still active.

Therefore, the main breakers on the system and plant side must be turned off.

Contact with the terminals may cause fatal electric shock.

The emergency stop switch has the following functions.


When the emergency stop switch is pressed, the operation of the system is stopped.

To reset the emergency stop state, turn the switch to the right.

The switch is initialized.


### 1.7.2 Operating procedure

1. When danger is detected, stay calm and press the emergency stop switch. The emergency stop switch will be in the off position.



**<Figure 6> Press the emergency stop switch.**

2. After pressing the emergency stop switch, machine operation is stopped. To release, the emergency stop switch must be reinitialized by turning it to the right. The emergency stop switch is in the operating position and operation is enabled.



**< Figure 7> Initialize the emergency stop switch.**

## **1.8 General safety instructions**

### **1.8.1 Precautions before operating the system**

Systems must be switched on only after checking that parts of the body (including some parts of the body and clothing) or materials can come into contact with the systems of the operating machine, or that similar hazards exist.

Start operation after removing all hazards that may cause personal injury.

1. General maintenance must be done completely before power on.
2. Restrict system operation and maintenance to personnel who have completed the minimum training in system use and maintenance.

### **1.8.2 Precautions when operating the system**

1. Check that there is no contact between the body (including some parts of the body and clothing) and the moving parts of the system.
2. When a problem occurs in the system, we try to thoroughly understand the situation and problem. When handling the system, the system must be turned off.
3. Make sure that no one except the operator enters the work area.
4. In case of abnormal operation, first stop the machine and cut off the power.

### **1.8.3 Precautions during maintenance**

1. Repair, calibration, control, replenishment or cleaning should be restricted to operators who are fully familiar with the system.

Turn off power and operate according to standardized procedures.

2. When the power is on, the system must be operated manually.

### 1.8.4 Cautions during maintenance

1. When performing maintenance work on the system, turn off the main power to prevent danger (such as electric shock) in advance.

2. The safety sensor must be used except for system maintenance or when not required.  
Before carrying out inspection operation, check that the safety sensor is operating normally.

**CAUTION:** When controlling, maintaining or repairing the system, you must read the above information and follow the safety regulations to avoid hazards and damage to the system.

### 1.8.5 Other important information

In addition to warnings and cautions, other important information is as follow.

For your safety, do not redesign the body and controls of the system.

When a problem occurs in the system, measure the condition and then address the problem.

Advise and ensure that no part of the body (including clothing) is drawn into moving parts of the system. Otherwise, it may cause a dangerous situation.

In case of an earthquake, storm, or fire, immediately stop the machine, turn off the power and cut off the power supply.

In order to prevent the system from operating incorrectly, block noise caused by other equipment to ensure correct operation.



## 2. Equipment Maintenance

### 2-1. Safety during inspection

#### 1. Safety rules

- ① Do not touch the sensor of each part arbitrarily.
- ② Access to each drive unit and transfer device is prohibited except for the person concerned when moving backwards and forwards.
- ③ In case of machine error or malfunction, be sure to take action after turning off the machine or manually.
- ④ Be sure to cut off the power to the facility and perform maintenance in Manual mode.
- ⑤ When working, be sure to work in groups of two or more.
- ⑥ Wear sufficient protective equipment during work.
- ⑦ Before work, be sure to attach a sign saying 'Working' on the Touch Panel.
- ⑧ After inspection, be sure to manually check the operation status and check for abnormal operation.

#### 2. Checklist before handling

In order to promote long-term use of the equipment and improvement of production, be sure to perform daily and weekly inspections.

- ① Are various sensors fixed and focused correctly?
- ② Are the supports and positions of each unit firmly fastened?
- ③ Is the air cleanliness of various cylinders, valves and regulators good?
- ④ Are various electric parts of the control panel firmly supported in their proper positions?
- ⑤ Is the single-phase 220V of the control panel normally supplied?
- ⑥ Are the terminal blocks and fastening parts of the control panel good?
- ⑦ Is the emergency switch function working properly?
- ⑧ Are there any parts that receive load such as mechanical jamming of the equipment?
- ⑨ Aren't unnecessary things interfering with the equipment before operating the equipment?
- ⑩ Are there no other workers in the facility when operating the equipment?

#### 3. Checklist while handling

Always inspect to prevent damage to equipment and to ensure human safety.

During operation of the equipment, inspect only the eyes, nose and ears.

- ① Is there no noise or foreign matter in the driving part?
- ② Are there any unnecessary noises while driving?
- ③ Did you restrict the access of people other than the person concerned?

#### 4. Inspection after handling

Inspect to make sure that the equipment will be operated in the future.

- ① Check that there is no leakage of oil such as lubricating oil from the equipment.
- ② Check that there is no leakage from cylinders, valves, and fittings.
- ③ Prepare for the next operation by performing a return to the origin of the equipment.
- ④ Keep the working environment clean and remove the surrounding hazards.
- ⑤ Visually inspect each part for deformation and damage.
- ⑥ Inspect bolt fastening in important parts and wear and damage of related parts.

## 2-2. Equipment Check

### 1) Checklist

- ① Check noise and heat during motor operation
- ② Check cylinder operation and each sensor operation
- ③ Check whether the driving part is connected to the coupling and whether it is damaged
- ④ Check the surface of the roller for dents and scratches
- ⑤ Check for interference between magnets
- ⑥ Check Idle Roller Level status

### 2) Trouble Shooting

Phenomenon	Cause	Measures
Motor Noise	Motor fixing Bolt loose	Fixing Bolt tightening
	Coupling breakage and loosening	Coupling replacement and tightening
Roller abnormality and noise	Magnet bad spacing	Magnet between Gap 2mm
	Bearing Housing Fixing Bolt loose	Fixing Bolt tightening
	Bearing Check for damage	Bearing replacement
Air Cylinder abnormal motion	Air pressure abnormal	Air pressure control (5~6 Kgf/cm <sup>2</sup> )
	Air Hose twisting, Leak Occurrence	Air piping Line inspection
	Sensor Bad detection, broken	Sensor or Dog Setting and Replacement

## 2-3. How to repair equipment

### 1) Precautions for maintenance

- ① Turn off the power.
  - Be sure to turn off the power before disassembling or repairing the product.
- ② Beware of electric shock
  - In case of unavoidable reasons to check the circuit while the power is connected, be especially careful not to touch the charging part (there is a risk of electric shock)
- ③ Use of appropriate parts
  - If parts need to be replaced, be sure to use genuine parts for the corresponding model.  
(Do not repair malfunctions of electrical contact parts, replace them with parts, and never modify the product.)
- ④ Use of appropriate tools
  - Use appropriate tools for repairs, and accurately adjust measuring instruments..
  - Using worn-out tools can cause accidents such as poor connection and poor contact.
- ⑤ Damaged wires and power cords
  - When repairing, check whether the power cord or wires are damaged, and be sure to replace damaged ones.
- ⑥ Intermediate connection of power cord is prohibited
  - Do not cut the middle of the power cord to make a middle connection or connect it from an outlet as it is very dangerous.  
It may cause malfunction or fire..

### 2) Checklist for maintenance

- ① Insulation check
  - After assembly is complete, be sure to check the insulation resistance.  
(Connect the power after checking that the insulation resistance of the power and ground terminals is over 300 MΩ using an insulation resistance meter.)
- ② Grounding check
  - Check the grounding condition and repair it if it is incomplete.
- ③ Check the installation status
  - Check the installation condition and repair any incomplete parts.

## 2-4. Equipment Routine Inspection

- ① Operate the equipment after checking the state of bolt connection in the driving part.  
Before operating the facility, check the loosening of the bolt and nut fastening parts of the main parts, and if loosening occurs, check the related dimensions according to the setting instructions.
- ② In case of abnormal noise from the motor and various driving parts, press the emergency switch, check the cause, and operate after taking action..
- ③ When adjusting equipment, turn off the power to prevent safety accidents.
- ④ Do not unplug the connection cable while the power is on.
- ⑤ LM Guide, Ball Screw part should be checked at least once a week, and the grease condition should be checked about once a month and injected if insufficient.
- ⑥ Do not touch the driving part while driving.
- ⑦ The adjustment and replacement period of consumables shall be adjusted and replaced at regular intervals when defects are found during the normal operation of the facility.
- ⑧ When electrical parts (Sensor, Auto S/W) do not operate due to damage or damage, it is possible to check through step operation. to refer to.
- ⑨ The pneumatic system is judged to be damaged due to air leakage, so if air is supplied to the main line before operating the facility, it is easy to find the leak and take action according to the size of the leak.

## 2-5. Equipment periodic inspection

Item	Inspection method	Inspection cycle
CDA Pressure	<ul style="list-style-type: none"> <li>Regulator Gauge pressure check 5.5 ~ 6.5 kgf/cm<sup>2</sup></li> </ul>	Everyday, Check regularly
Regulator	<ul style="list-style-type: none"> <li>Residual pressure drain with the button at the bottom of the regulator</li> <li>Turn the filter case to clean with air</li> </ul>	1 time / 6 months
Cylinder	<ul style="list-style-type: none"> <li>Touch Panel movement Check</li> <li>Speed Setting With Speed Controller</li> </ul>	In case of abnormal operation
Lubrication of drive part	<ul style="list-style-type: none"> <li>LM Guide, Bearing, Power Base Cleanliness</li> <li>Inspect the drive condition and inject grease</li> </ul>	1 time / 6 months
Sensor	<ul style="list-style-type: none"> <li>Combination state of Sensor and Connector</li> <li>Disconnection</li> </ul>	1 time / Monthly, In case of abnormal operation
Positioning Unit	<ul style="list-style-type: none"> <li>Wear condition and assembly condition of parts</li> </ul>	1 time / 6 months, In case of abnormal operation
Motor	<ul style="list-style-type: none"> <li>Combination state in case of noise or abnormal operation</li> <li>Disconnection</li> </ul>	In case of abnormal operation

EMO S/W	<ul style="list-style-type: none"> <li>• Check return operation after push</li> </ul>	1 time before equipment start-up
electricity	<ul style="list-style-type: none"> <li>• Check the connection state of the terminal block inside the control panel</li> </ul>	1 time / 3 months

## 2-7. Equipment failure causes and measures

Fault condition	Cause	Measures
Motor not driven	• cut off power supply	• Measure the voltage of the motor
	• short circuit in electrical lines • Bad contact of Magnet Contactor in Motor	• After checking the voltage, repair the defective part
Motor noise	• Damage to stator wires	• Line resistance measurement and insulator and line condition check
	• Bad contact of Magnet Contactor in Motor	• Repair after voltage and current check
	• Impurities	• Remove impurities
Bearing noise	• abnormal load	• Check the degree of fit and pressure, and adjust the housing
	• Bad installation	• Shaft Housing Level adjustment
	• abutment of contact	• Contact area adjustment
Regular noise	• Scratches on rotating parts	• Grease application and Remove impurities
	• Break	• replacement
	• Scratch	• replacement
Irregular noise	• Impurities	• Grease application and Remove impurities
	• Scratch	• replacement
Abnormal temperature rise	• Bad viscosity of grease	• Replace and apply appropriate grease
	• Grease lack	• Grease supplement
Vibration	• Break	• replacement
	• Scratch	• replacement

1) When cleaning the bolts of the Air Service Unit (F.R.L), chemicals such as thinner, carbon tetrachloride, alcohol, and acid should not be used.

2) Do not allow air mixed with moisture to enter the pneumatic equipment.

3) Check that the grease nipple of the bearing unit is always filled with grease and reaches the bearing at least twice a month.



#### 4) General management

After one week of operation, check the condition of all coupling parts (joints of bolts and nuts), and check the condition of coupling once a month in the first year. If the coupling is loose, action must be taken immediately.

After one year, check once every six months, and take immediate action if necessary.

First, within one year after installation, all pneumatic cylinder parts, bearings, motors, and all other driving parts must be inspected, replaced if necessary, and then inspected once every six months.

Second, if the coupling is loosened during operation, immediate action must be taken.

Third, if foreign matter falls into the driving part or the pneumatic piping flexible cable, it must be removed immediately..

## 2-8. Pneumatic System Periodic Inspection

#### 1) Daily inspection

- The condensed water in the filter of the service unit must be drained every day.  
(In general, most large pneumatic systems have automatic drainage.)

#### 2) Weekly inspection

- Clean the foreign matter of the signal input element.
- Check and check the pressure control condition of the pressure regulator.

#### 3) Inspection every 3 months

- Check for pneumatic leakage at the connection port.
- Check the exhaust ball of the valve.

#### 4) Inspection every 6 months

- Check the wear condition of the rod bearing in the cylinder. Replace the sealing if necessary.

## 2-9. Equipment abnormalities measures

### ► Measures in case of motor abnormality

#### 1) Motor fault diagnosis

The cause of failure of the motor is caused by various causes such as deterioration of the equipment due to long-term use or poor maintenance, inspection, and maintenance. Some of these causes overlap or one cause causes another. , there are many cases of failure due to complex entanglement.

#### 2) Failure cause

Failure cause	Example
What is due to main circuit condition	Voltage fluctuation, disconnection of wiring, malfunction of switch, etc.
Attributable to load or operating conditions	Overload, high frequency start, heavy inertia load, etc.
What is caused by the surrounding environmental conditions	High temperature, high humidity, dust, corrosive gas, vibration, etc.
What is caused by bad installation and construction	Weak foundation (floor), Bad centering, improper belt tension
Things caused by bad maintenance, inspection, and maintenance	Negligence in supplying grease or exchanging brushes, etc.
Attributable to defects in motor manufacturing	Bad assembly, contamination of foreign matter, etc.
Caused by driving operation error	Misoperation, etc.
Attributable to secular life span	Deterioration of ferrous materials, wear of bearings, etc.

#### 3) Impact on failure

A failure of the motor suddenly stops the operation of the load machine driven by it. In some cases, the failure of one motor of small capacity causes a ripple accident in which the production line of the factory is stopped, resulting in enormous damage.

Therefore, it is necessary to actively prevent equipment breakdowns and various disasters caused by them by conducting planned maintenance and inspection.

Even if a breakdown occurs, prompt first aid measures should be taken, and at the same time, efforts should be made to prevent the spread of the accident, and the cause of the breakdown should be pursued to prevent recurrence.

#### 4) Motor failure measures

Anomaly	Cause	Measure
Motor Overheating	Not wired according to the wiring diagram in the Thermal Box.	Rewiring
	The supply voltage is 5% higher than the rated voltage of the motor.	Make sure the rated voltage of the motor is supplied.
	Over Load. Excessive current flows. The pace is too slow.	Replace with a motor that can produce the required output
If the motor does not start	NFB is down	Raise NFB after removing the cause
	Bad wiring	Rewiring
If the motor does not run smoothly	Not wired according to the wiring diagram in the Thermal Box.	Rewiring
	Supply the required voltage or current value for operation	Improvement after checking supply power
Motor hums and excessive current flows.	Motor Coil Winning Bad	Motor repair
	Motor rubs against the inside	
NFB or thermal relay frequently splashes	Circuit short on wiring	Remove shorted circuit
	Motor Circuit Short	Remove shorted circuit
	wiring Miss	Rewiring
Wrong direction of rotation	Incorrect motor wiring	Change the wiring of the incoming main power

#### 5) Examples of measures to prevent motor equipment failure

When it is cold, the viscosity of the grease used for the bearing of the motor or the lubricating oil of the load machine may increase due to the low temperature, resulting in an increase in the starting torque. In significant cases, the motor may not start and may become overloaded.

In this case, it is necessary to select grease and lubricating oil suitable for the operating conditions, and at the same time to properly set the overload protection relay in the motor so that reliable operation is possible.

## 6) Fault cause and handle

Failure situation	Cause	Handle
Unable to start	The power is not turned on and the voltage is low.	Circuit breaker inspection, power supply voltage inspection
	overload	load check
	Bearing seizing (burning)	Bearing repair
Circuit breakers or thermal breakers	Inadequate selection of rated current	change rated current
	Internal failure of the motor	Motor internal inspection and repair
	overload	Optimization of load
Bad acceleration	Improper starting method	Start-up method review
	Defective control circuit	control circuit check
	voltage drop is large	Examination of power capacity, replacement of wiring size
Overheating of the motor Smoke generation	overload	Optimization of load
	Bad ventilation	Inspection of the cooling ventilation part
	single phase operation (For 3 phase induction motor)	Check for disconnection. Inspection of control mechanism contact failure
	Interfloor paragraph	electric motor repair
Abnormal vibration Abnormal noise	Bad installation	Inspection of foundation and fixing bolts
	Bad direct connection	Centering adjustment
	Bad Bearing	Bearing repair or replacement
	unbalance of load machine	Balancing the load machine

## - Maintenance and inspection cycle

Periodic inspections perform inspections, adjustments, and function inspections of areas deemed necessary based on the results of daily inspections. It is desirable to make an integrated decision while looking at the results of the inspection.

## ► Countermeasures in case of pneumatic system failure

### 1) Malfunction and breakdown

Malfunctions and failures are likely to occur under the following conditions.

- ① Natural wear and tear of pneumatic components and piping is significantly accelerated by the influence of the external environment, compression, and air conditions.
- ② Wear of parts can cause malfunction, leakage of air pressure, and damage to other parts.
- ③ Contaminated air can increase abrasion inside pneumatic components and cause malfunctions due to clogging and clogging.
- ④ Piping can be clogged, cracked or bent due to internal and external environmental factors.
- ⑤ Accumulation of foreign substances may cause pressure drop and consequently inaccurate switching due to resistance from piping or pneumatic components.
- ⑥ Inaccurate switching may occur due to pressure drop due to leakage or pulsation of supply pressure. Inaccurate switching can also occur if the filter is clogged and does not supply enough pressure.
- ⑦ Inaccurate fitting with the cylinder or overload can also cause early wear. In terms of cost, it may be slightly more expensive, but it lowers the frequency of malfunctions and can reduce failures even more.

Important preventive measures include.

- Use the right parts that are well harmonized with the surrounding environment conditions and control sequences. (Fully review the technical data for each part.)
- Select an appropriate mounting type and use a solid cylinder in a place where a large load or side load is applied.
- When the acceleration force is large, a shock-absorber is installed to absorb the operating force.
- If there is a lot of dust and foreign substances, use a self-cleaning cover.
- Securely fix the mounting adjustment screw of the cylinder and the signal input element.
- To prevent signal delay, make the pipe as short as possible.
- Ensure the exhaust of the control and power valves.

### 2) Failure in pneumatic system

In general, if the initial failure is excluded, the pneumatic system operates well for a certain period of time without failure. Even with some initial wear, it may not be noticeable for weeks or months. Moderate wear and tear may go unnoticed for years. The effects of wear or defects are not easy to detect unless they directly affect the part.

The problem is that erroneous operation occurs in the control sequence due to these causes. In the previous chapter, the causes of malfunctions and prevention methods have already been described, but not all situations in which they can occur. What is mentioned here is limited to malfunctions and pneumatic systems that can occur frequently. Even in a very complex control system, it is necessary to analyze in detail by dividing it into small parts with the help of various data. The operator should be able to eliminate the failure immediately and at least identify the cause to prepare for the next time.

Where a service engineer is needed, it can be easily solved because the service engineer knows most of the cause of the failure and special tools and spare parts are prepared, but it is desirable for the operator to notify the basic situation by phone in advance.

If the cross section of the pneumatic system suddenly increases in a situation where air is not sufficiently supplied, malfunction often occurs. Since these malfunctions do not continuously occur but occur sporadically, it is difficult to find the cause of the malfunction.

When this situation occurs, the cylinder cannot exert its power due to a sudden pressure drop, and the operating sequence may be wrong due to the power valve's malfunction. This phenomenon may be caused by contamination of pipes or leakage of air.

If the diameter of the pipe is reduced by 20%, the pressure drop doubles, so care must be taken. As mentioned in the preparation stage of compressed air, moisture in compressed air must be removed.

In practice, what happens when the amount of moisture in the compressed air increases? Aside from being damaged by the corrosive action of moisture, it has a significant adverse effect on valves.

That is, if the valve stays in one control position for a very long time, it causes a malfunction and prevents proper operation.

In particular, care must be taken because it becomes an emulsion or a resin when mixed with lubricating oil to block the operation of the valve.

The thing to be careful about in the piping is to clean the inside of the piping before connecting it. Otherwise, foreign substances generated during pipe connection work or welding work - sealing tape welding beads, pipe rust, screwing dregs, etc. flow into the pneumatic system and adversely affect it. The effects of these foreign substances are summarized as follows.

- ① Adherence of slide valve
- ② Continued leakage by sticking to the seat of the poppet valve
- ③ It sticks to the one-type nozzle of the flow control valve and interferes with precise speed control, and the cylinder speed decreases over time.

### 3) Cylinder failure

The failure of a pneumatic cylinder can be identified if it is damaged by observing it well even when the cylinder is operating well.

Observe periodically to see if there is any damage and take action.

Cylinders that exercise with heavy loads over long distances are prone to abrasion on the rod seal side. Lubricating oil adheres to the piston rod, making it easy to move in an unstable state. In this case, check whether the piston rod is covered with a black lubricant film.

In this state, it is easy for the piston to exercise while generating intense vibration.

Even a slowly moving cylinder can be damaged by abrasion of the piston seal, dry mixture of grease, and rubber particles accumulated in the cylinder barrel.

Next, you can judge the cylinder's abnormality by sound. If air leaks from the cylinder during forward/backward movement of the cylinder, you can clearly hear a "shhh" sound. At this time, check the condition of the sealing used in the cylinder.

Methods to prevent malfunctions in pneumatic cylinders are presented below.

- ① When replacing sealing parts during maintenance, clean the inside of the cylinder to completely remove oil and grease residues, then inject new grease.
- ② Piston Rod periodically removes these foreign substances so as not to be damaged by dust or deposits.
- ③ Since the cylinder is a linear element, it is designed to be strong only in the axial direction, so use it so that no load is applied in the radial direction.  
When such a load is applied, the piston rod bearing is quickly damaged and the durability of the sealing cannot be guaranteed.
- ④ Use lubricated air for the cylinder and adjust the amount of lubrication appropriately.  
Excessive lubrication should be avoided where possible..

## 2-10. Equipment Lubrication and Lubrication Guidelines

### ► Purpose of refueling

It is absolutely necessary to extend the life of equipment, reduce noise generated during operation, and prevent wear of machinery.

### ► How to refuel and where to refuel

#### 1) Lubrication

Depending on the lubrication method and the suitability of the lubricant, it has a significant influence on the lifespan, and grease lubrication is widely used as a general lubrication method.

Grease is a semi-solid lubricant consisting of base oil, thickener and additives.

Even for the same type of grease, there is a big difference in performance depending on the name (different for each manufacturer), so care must be taken in selection.

##### ① base oil

Synthetic oils such as mineral oil, silicone oil, and diesel oil are used for grease base oil.

Since the lubricity of grease is mainly determined by the lubricating performance of the base oil, the viscosity of the base oil should be considered as important when selecting a lubricant. In general, grease with low viscosity oil is suitable for low temperature or high speed, and grease with high viscosity oil is suitable for high temperature or high load.

Alternatively, silicone oil has a wide temperature range from low to extremely high temperatures, can be suitable for low and medium speeds, light and heavy loads, and is used for special purposes due to its excellent water resistance and wide mechanical stability.

##### ② Thickener

In addition to metal soap, inorganic thickeners such as silica gel and bentonite and heat-resistant organic thickeners such as poly-urea and fluorine compounds are also used as thickeners for lubricating grease. There is a close relationship between the type of thickener and the dropping point of the grease, so grease with a high dropping point generally has a high operating temperature. However, greases containing sodium soap in addition to greases using high dropping point thickeners are not suitable for places exposed to water or high humidity as they emulsify.

##### ③ Additives

Antioxidants, rust inhibitors, and extreme pressure agents are added to grease as needed.

Grease with an extreme pressure agent is used in conditions of use under heavy and impact loads, and grease with an antioxidant is selected when long-term lubrication is required.



#### ④ lead

Grease consistency indicates the degree of hardness of the grease, which refers to the internal resistance to withstand deformation caused by external force, and is indicated as a grade number determined by the NLGI (National Lubricating Grease Institute). Grease used for roller bearings is NLGI grade number 1-3 am.

#### ⑤ Injection amount of grease

In general, the injection amount of grease is enough to fill 30~50% of the bearing and housing space, and if too much is injected, there is a risk that the temperature rises rapidly at high speed rotation.

However, at low speed, completely filling the grease is effective in preventing corrosion.

#### ⑥ Mixing of Grease

In case of using the same grease that was used for refueling, it should be reviewed first whether it can be mixed. If the injections do not mix well with each other, the consistency will be lowered or the maximum allowable speed will be lowered. Greases with the same thickener and similar base oil can be mixed with each other.

#### ⑦ Grease re-injection interval

Grease re-injection interval depends on the bearing type, size, temperature, speed, and used grease, and it is desirable to shorten the life span of the grease.

Small bearings have a slightly longer lifespan, so the re-injection interval is slightly longer than normal, and medium-sized or large-sized bearings are injected at regular intervals.

#### ⑧ Lubrication of Bearing

It is a grease nipple, and if there is no grease after regular inspection (about 3 months), it is recharged with a grease gun.

#### ⑨ Grease injection device

##### ■Grease Gun

The grease filled in the bearing is usually lubricated using a manual grease gun.

Grease gun uses a simple piston-operated device to squeeze grease into the bearing through the nipple installed in the bearing housing.

At this time, new grease is supplied into the housing through the nipple to push out the deteriorated grease filled in the bearing, and new grease is squeezed out until the new grease is pushed out of the housing..

##### ■Grease Nipple

Grease Nipple generally has a structure of a valve using a ball and spring, which plays a role in preventing grease from flowing back or infiltration of external contaminants. The

shape and form of the nipple differs depending on the connection method of the gun. Therefore, when the grease gun is changed, the shape of the nipple is also changed, and by doing so, it is possible to prevent mishaps caused by incorrectly injecting different types of grease.

### 3. Outline

#### 3-1 Equipment Name

- HEATSINK HOLDER INSERTER


#### 3-2 Equipment Outline

- Equipment that fastens the holder that is automatically supplied to the heatsink to the designated point

#### 3-3 Apply MODEL

- HEATSINK

#### 3-4 Equipment Layout & Interlock location



## 4. Equipment Specifications

### 4-1 Equipment SIZE

- Lay-out Size :
- 1260(W)\*3390(L)\*1700(H)

### 4-2 Equipment Ability

- a) TACT TIME :
- b) Working conditions : Insertion of materials using conveyor Insertion and fastening of heatsink holder


### 4-3 UTILITY

- a) ELECTRIC POWER SOURCE :  
AC220V $\pm$ 10%, 1  $\phi$  4.5Kw 20A
- b) Control Power : DC 24V
- c) Clean Dry Air : 5~6 kg/cm<sup>2</sup>

### 4-4 Equipment Installation Use Environment


- a) Temperature range : -10°C~40°C
- b) Humidity range : 40% ~ 60%
- c) Altitude : 4.7M

Name plate installation location (notation)



## 5. Basic Equipment Specifications

### 5-1. FRAME UNIT



#### ► Main features and characteristics

- Unit component installation frame, touch panel installation part for facility operation


#### 1) Structure

- Composed of lower structure profile
- Composed of upper structure profile

#### 2) Main components

- Touch Panel : TOPRW1000WD 102"
- Door Sensor : D40A-1C2(Omron)

## 5-2. IN PUT CONVEYOR UNIT



### ► Main features and characteristics

- A device that transports manually supplied heatersink to a designated location


#### 1) Structure

- Composed of Profile
- Belt rotation by motor drive
- Y-axis has variable motion according to product width

#### 2) Main components

- Servo Motor : HG-KN23 & MR-JE-20B(Mitsubishi)
- AC Motor : S7I15GX-S12CE & SEX02CE(SPG)

### 5-3. TRANSFER UNIT



#### ► Main features and characteristics

- Aligned by heatsink size and a device that transports them to each process location


#### 1) Structure

- Composed of orthogonal robots
- Variable motion is made according to the length of the X-axis product

#### 2) Main components

- ROBOT : HS-75-S20-N2B-0550-R20(Hanshin ROBOT)
- Servo Motor : HG-KN13 & MR-JE-10B(Mitsubishi)
- Servo Motor : HG-KN23 & MR-JE-20B(Mitsubishi)

## 5-4. REVERSE UNIT



### ► Main features and characteristics

- Heatsink holder fastened finished product 180 degree direction change and discharge device

#### 1) Structure


- Composed of assembly of processed products

#### 2) Main components

- Servo Motor : HG-KN13 & MR-JE-10B(Mitsubishi)
- BLDC Motor : WGW40-BL4263M-24V-49 & BDD-240(Motor Bank)
- Air Cylinder : CDU25-60D-A93S(SMC)



## 5-5. HOLDER SUPPLY UNIT



### ► Main features and characteristics

- Feeder for holder supply
- A device that detects the holder supply color classification and detects the presence or absence of the spring attached to the holder and discharges defects


#### 1) Structure

- Composed of assembly of processed products

#### 2) Main components

- Feeder : BOWL & LINEAR FEEDER(HYUPJIN FEEDER)
- Servo Motor : HG-KN13 & MR-JE-10B(Mitsubishi)
- Air Cylinder : CDU16-30D-A93 (SMC)
- Air Cylinder : MHZ2-10-M9BS(SMC)
- FIBER UNIT : FT-420-10(AUTONICS)
- FIBER AMP : BF4R(AUTONICS)

## 5-6. HOLDER INSERTER UNIT



### ► Main features and characteristics

- Supply of Holders to connect Holdes to Heatsinks,  
A device that fastens X, Y-axis moving holders with a fixed pitch


#### 1) Structure

- Composed of assembly of processed products in the profile assembly structure

#### 2) Main components

- Servo Motor : HG-KN13B & MR-JE-10B(Mitsubishi)
- Servo Motor : HG-KN23 & MR-JE-20B(Mitsubishi)
- Sensor : GTD6-N1211(SICK)

## 5-7. RETURN CONVEYOR UNIT



### ► Main features and characteristics

- A device that returns the assembled product to the worker's position in case of small quantity production


#### 1) Structure

- Composed of assembling processed products in the profile structure

#### 2) Main components

- Motor : S9I90GX-S12CE & SRX02CE
- Sensor : GTD6-N1211

## 5-8. OUTPUT CONVEYOR UNIT





### ► Main features and characteristics

- A device that transfers the finished product to the downstream equipment
- 1) Structure
  - Composed of assembling processed products in the profile structure
- 2) Main components
  - Motor : S9I90GX-S12CE & SRX02CE

## 6. Mechanism Drawing

## 6-1. Assembly Drawing






番号	品名	寸法	寸数	材料	単位
P201	DIGITEC	5.7×40×45	6	S-303	個
P202	LEVEL TEST	FR-420×200	6	S-303	個
P203	LEVEL TEST	FR-200×150	8	S-303	個
P204	NOON 20×40	20×40×25	8	S-303	個
P205	NOON 40	81.7×90×40	6	S-303	個
P206	NOON 40	FR-200×200	6	S-303	個

$\Delta$			
$\Delta$			
2018	2017/2018	2016	2015/2016

 SCALE 1/50		 PROJECT NAME	
 DRAWING NO. 100		 PART NAME	
 DATE		 REV. NO.	
 DRAWING NO. 100		 DRAWING NO. 100	
 DRAWING NO. 100		 DRAWING NO. 100	
 DRAWING NO. 100		 DRAWING NO. 100	

[illegible]




4			
5			
6			
7	8	9	10

[illegible]





400




REV	DATE	DESCRIPTION	BY	CHK	DATE	DESCRIPTION	BY	CHK	DATE
1		INITIAL							
2		REVISION							
3		REVISION							
4		REVISION							
5		REVISION							
6		REVISION							
7		REVISION							
8		REVISION							
9		REVISION							
10		REVISION							
11		REVISION							
12		REVISION							
13		REVISION							
14		REVISION							
15		REVISION							
16		REVISION							
17		REVISION							
18		REVISION							
19		REVISION							
20		REVISION							
21		REVISION							
22		REVISION							
23		REVISION							
24		REVISION							
25		REVISION							
26		REVISION							
27		REVISION							
28		REVISION							
29		REVISION							
30		REVISION							
31		REVISION							
32		REVISION							
33		REVISION							
34		REVISION							
35		REVISION							
36		REVISION							
37		REVISION							
38		REVISION							
39		REVISION							
40		REVISION							
41		REVISION							
42		REVISION							
43		REVISION							
44		REVISION							
45		REVISION							
46		REVISION							
47		REVISION							
48		REVISION							
49		REVISION							
50		REVISION							
51		REVISION							
52		REVISION							
53		REVISION							
54		REVISION							
55		REVISION							
56		REVISION							
57		REVISION							
58		REVISION							
59		REVISION							
60		REVISION							
61		REVISION							
62		REVISION							
63		REVISION							
64		REVISION							
65		REVISION							
66		REVISION							
67		REVISION							
68		REVISION							
69		REVISION							
70		REVISION							
71		REVISION							
72		REVISION							
73		REVISION							
74		REVISION							
75		REVISION							
76		REVISION							
77		REVISION							
78		REVISION							
79		REVISION							
80		REVISION							
81		REVISION							
82		REVISION							
83		REVISION							
84		REVISION							
85		REVISION							
86		REVISION							
87		REVISION							
88		REVISION							
89		REVISION							
90		REVISION							
91		REVISION							
92		REVISION							
93		REVISION							
94		REVISION							
95		REVISION							
96		REVISION							
97		REVISION							
98		REVISION							
99		REVISION							
100		REVISION							



REV	DATE	DESCRIPTION	BY	CHK
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				
86				
87				
88				
89				
90				
91				
92				
93				
94				
95				
96				
97				
98				
99				
100				

REV	DATE	DESCRIPTION	BY	CHK
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				
86				
87				
88				
89				
90				
91				
92				
93				
94				
95				
96				
97				
98				
99				
100				





609


[illegible]

DATE	REVISED	ECN.	REVISED
DATE	REVISED	ECN.	REVISED
DATE	REVISED	ECN.	REVISED
DATE	REVISED	ECN.	REVISED

[illegible]



800



REV	DATE	DESCRIPTION	BY	CHK	APP	QTY	UNIT	PRICE	TOTAL
1	10/10/10	REVISED	1	10	10	10	10	10	10
2	10/10/10	REVISED	1	10	10	10	10	10	10
3	10/10/10	REVISED	1	10	10	10	10	10	10
4	10/10/10	REVISED	1	10	10	10	10	10	10
5	10/10/10	REVISED	1	10	10	10	10	10	10
6	10/10/10	REVISED	1	10	10	10	10	10	10
7	10/10/10	REVISED	1	10	10	10	10	10	10
8	10/10/10	REVISED	1	10	10	10	10	10	10
9	10/10/10	REVISED	1	10	10	10	10	10	10
10	10/10/10	REVISED	1	10	10	10	10	10	10


REV	DATE	DESCRIPTION	BY	CHK	APP
1	10/10/10	REVISED	1	10	10
2	10/10/10	REVISED	1	10	10
3	10/10/10	REVISED	1	10	10
4	10/10/10	REVISED	1	10	10
5	10/10/10	REVISED	1	10	10
6	10/10/10	REVISED	1	10	10
7	10/10/10	REVISED	1	10	10
8	10/10/10	REVISED	1	10	10
9	10/10/10	REVISED	1	10	10
10	10/10/10	REVISED	1	10	10

REV	DATE	DESCRIPTION	BY	CHK	APP	QTY	UNIT	PRICE	TOTAL
1	10/10/10	REVISED	1	10	10	10	10	10	10
2	10/10/10	REVISED	1	10	10	10	10	10	10
3	10/10/10	REVISED	1	10	10	10	10	10	10
4	10/10/10	REVISED	1	10	10	10	10	10	10
5	10/10/10	REVISED	1	10	10	10	10	10	10
6	10/10/10	REVISED	1	10	10	10	10	10	10
7	10/10/10	REVISED	1	10	10	10	10	10	10
8	10/10/10	REVISED	1	10	10	10	10	10	10
9	10/10/10	REVISED	1	10	10	10	10	10	10
10	10/10/10	REVISED	1	10	10	10	10	10	10

HEAT SINK HOLDER INSISTER  
OUTPUT CONVERTER UNIT  
HOLDING-800

## 6-2. Consumable Parts

7. Pneumatic Circuit Diagram



## 8. Purchasing Item LIST

[illegible]



**9.Parts Catalog(Attached)**

# Electrical Manual

## Index

1. Equipment Specifications
2. POWER ON Procedure
3. Touch Screen Description
  - 3-1. Screen Layout
  - 3-2. Main Screen
  - 3-3. Manual Screen
  - 3-4. Monitor Screen
  - 3-5. Data Screen
  - 3-6. Velocity Data(Model Common Data)
  - 3-7. Home
  - 3-8. Acc / Dec(Model Common Data)
  - 3-9. Limit(Model Common Data)
  - 3-10. Servo Power
  - 3-11. Load Factor
  - 3-12. Use / Unuse
  - 3-13. Delay Time (Model Common Data)
  - 3-14. Model
  - 3-15. Alarm
  - 3-16. Emergency Stop Screen
  - 3-17. Signal Tower
  - 3-18. Door Interlock Switch Description And Location
  - 3-19. Safety Procedures For Invalidation Door Interlock Switches
  - 3-20. Tag out
    - 3-20-1. LOTO (Log out / Tag out) Procedure
  - 3-21. System Precautions
    - 3-21-1. Caution On High-Voltage Part
4. Electric Drawing
5. Electric Part LIST
6. Electric Parts Catalog(Attached)

# 1. Equipment Specifications

## 1-1. Equipment Name

- HEATSINK HOLDER INSERTER

## 1-2. Equipment Outline

Equipment that fastens the holder that is automatically supplied to the heatsink to the designated point

## 1-3. UTILITY

- ELECTRIC POWER SOURCE :

AC220V $\pm$ 10%, 1  $\phi$  4.5Kw 20A

- Control power : DC 24V

## 2. POWER ON



- POWER ON Status check (GPS LAMP ON).
- \*\* POWER LAMP always ON \*\***  
(LAMP turns off when main power POWER is OFF.)




- Turn the handle to the MAIN POWER S/W ON position.
- \*\* POWER LAMP(UPS&GPS) always ON (Refer to the contents above) \*\*** (When turning ON the POWER handle, check the DOOR CLOSE status.)



- Magnet operates when EMO RESET S/W is ON.



- EMO RESET ON.
- \*\* EMO status check before POWER LAMP(UPS) ON \*\***  
(DOOR is in CLOSE status (requires thorough key management))




- TOUCH Equipment Handling MODE GROUP ON.

# 3. Touch Screen Description

## 3-1. Screen Layout

### < MAIN SCREEN >



### < Manual control settings GROUP > < System and I/O monitor GROUP >




### < SERVO Parameter setting GROUP > < RECIPE setting GROUP >



### < Equipment OPTION select GROUP > <ALARM HISTORY mark GROUP >



### 3-2. MAIN Screen




This is the initial screen. When you press the button, you can move to the corresponding screen.

- Ready : It is an operation preparation button for initial automatic operation.
- Auto Start : It is a button for automatic operation when operation preparation is completed.
- Stop : A button to stop the equipment. Manual operation is possible when this button is lit..
- Pause : This button is used to temporarily stop the equipment. Even when an alarm occurs, this button is activated.
- LOT FINISH : This button is used to complete the work without inserting the product.
- Reset : This button flickers when an alarm occurs. If you release the alarm situation and press this button, the light goes out.
- Buzzer Stop : The buzzer operates when an alarm occurs. This button is used to stop the buzzer.

### 3-3. Manual Screen

#### - Input conveyor



#### - Manual output operation button



- Units on the input conveyor can be operated manually.
- You can check whether manual operation is possible.

#### - Conveyor Explosion



- Conveyor width can be moved to the location saved in the model.
- You can check whether manual operation is possible.


#### - Side menu -



- Move to the GROUP UNIT manual screen according to the location.



## - Heat Sink Transfer Unit Manual Screen




## - Heat Sink transfer unit



- Tilting chuck and alignment jig can be operated manually..
- You can check whether manual operation is possible.

## - Tilting Explosion



- You can manually operate the tilting axis to the standby position and working position.
- You can check whether manual operation is possible.


## - Transfer unit-X axis




- You can manually operate the transfer unit x-axis to the standby position, working position, abaxial position, and discharge position 2.
- You can check whether manual operation is possible.



## - Holder insert unit manual screen



## - Holder insert unit




- Hold shooting can be operated manually.
- You can check whether there is a product in the insertion part or the press-fitting part.
- You can check whether manual operation is possible.

## - Insert unit X, Y axis




- You can manually operate the X and Y axes of the insertion unit..
- You can change the insertion position by changing the number with – or +.
- You can check whether manual operation is possible.

## - Insert, press Z axis




- The Z-axis of the insertion unit can be manually operated.
- If you change the numbers with – and + on the insertion unit, you can change the insertion and press-in position.
- You can check whether manual operation is possible.

## - Holder supply unit manual screen




## - Holder supply unit




- Units required for hold supply can be manually operated.
- You can check whether manual operation is possible.

## - Holder transfer unit



- The hold transfer unit can be operated manually.
- You can check whether manual operation is possible.

## - Reversal unit manual screen




## - Reversal unit



- The grip cylinder of the reversal and the conveyor can be operated manually.
- You can check whether manual operation is possible.


## - Reversal-θ axis unit



- The position of the reversal can be manually operated.
- You can check whether manual operation is possible.



## - Return / Output Conveyor Unit Manual Screen




## - Return / Output Conveyor Unit




- The return/output conveyor can be operated manually by RUN/STOP.
- You can check whether manual operation is possible.

### 3-4. Monitor Screen




### - System monitor



- If the operation preparation lamp continues to flicker during the main, operation preparation process, it is a screen to check which part is the problem.

- DOOR MONITOR




- This is a screen that can be checked when a Door Open Error occurs.

## - In/Out Monitor



- You can check the input/output I/O.-



■ You can check the I/O number and name.

\*\* When the I/O is ON, the lamp turns yellow/blue \*\*



■ You can move the screen to another I/O GROUP.




### 3-5. Data Screen

<b>Data</b>		<b>Model</b> 000	<b>Base No</b> 300		0 yy 0m 0d 0 : 0	
<b>Servo Setting</b>						
Position Data	Velocity Data	Home	Acc/Dec	Limit		
	Common Data		Common Data	Common Data		
Servo Power	Load Factor					
<b>Use/Unuse</b>	<b>Delay Time</b>	<b>Real Time Change</b>	<b>Password Change</b>	<b>Manager</b>		
Use/Unuse	Delay Time	Real Time Change	Password Change	Idle		
	Common Data			HOLDER SHOOT TEST		
Main	Manual	Monitor	Data	Model	Alarm	Ver:2307



## - Position Data

### - Conveyor width position data



After moving the position with JOG, select the position to be saved and press the current value save button of the relevant axis for 0.5 second to move the servo current position to that position.

The last data save button must be pressed for 1 second to save.

- Conveyor width can be set.
- After changing, press and hold the data save button for 1 second to save.

### -SERVO status display-



- -,H,+,Home,Error : You can check the RLS, HOM, FLS, homing completion status, and servo error status of the servo.

## - Heat sink transfer position data

Position Data Model 000 Base No 302 0 yy 0m 0d 0 : 0

mm mm PV = Present Value

Chuck -W Axis	SM02 - X	Transfer -X Axis	SM03 - X
PV Pos	0.000	PV Pos	0.000
PV Save	PV Save	PV Save	PV Save
Wait Pos'	0.000	Wait Pos'	0.000
Working Pos'	0.000	Working Pos'	0.000
		Output Pos'	0.000
		Output Pos'2	0.000

Mechanical Tolerance 0.000

Common Tasks JOG

Position Velocity

C/V Width Position C/V Width Velocity

Transfer Position Transfer Velocity

Insert Part Position Insert Part Velocity

Supplier Position Supplier Velocity

Reversal Position Reversal Velocity

Data Read Home

Data Save Acc/Dec

Limit

0 / 0 / 0

0 : 0

Main Manual Monitor Data Model Alarm Ver:2307

- You can set the tilting chuck width axis and the heat sink trans-X axis.
- After changing, press and hold the data save button for 1 second to save.

## - Holder insert position data

Position Data Model 000 Base No 303 0 yy 0m 0d 0 : 0

mm mm degree degree

Holder Insert Unit	SM04 - X	SM05 - Y	SM06 - Z1	SM07 - Z2
PV Pos	0.000	0.000	0.000	0.000
PV Save	PV Save	PV Save	PV Save	PV Save
Wait Pos'	0.000	0.000	0.000	0.000

Number

Insert Quantity (MAX:9) 0

JOG

Position Velocity

C/V Width Position C/V Width Velocity

Transfer Position Transfer Velocity

Insert Part Position Insert Part Velocity

Supplier Position Supplier Velocity

Reversal Position Reversal Velocity

Data Read Home

Data Save Acc/Dec

Limit

0 / 0 / 0

0 : 0

Main Manual Monitor Data Model Alarm Ver:2307

- It is possible to set the holder insertion and press-in positions (up to 9 possible).
- After changing, press and hold the data save button for 1 second to save.

## - Holder supply position data

Position Data Model 000 Base No 304 0 yy 0m 0d 0 : 0

Degree SM08 - 0 PV = Present Value

Holder Trans - 0 Axis Home Error

PV Pos 0.000

PV Save PV Save

Receive Wait Pos 0.000

Receive Pos 0.000

Give Pos 0.000

Holder Color Number 0 1 : BLUE 2 : BLACK 3 : YELLOW JOG

Position Velocity

C/V Width Position C/V Width Velocity

Transfer Position Transfer Velocity

Insert Part Position Insert Part Velocity

Supplier Position Supplier Velocity

Reversal Position Reversal Velocity

Data Read Home

Data Save Acc/Dec

Limit

0 / 0 / 0 Limit

0 : 0

Main Manual Monitor Data Model Alarm Ver:2307

- Holder transfer position and color can be set.
- After changing, press and hold the data save button for 1 second to save.

## - Reversal position data

Position Data Model 000 Base No 305 0 yy 0m 0d 0 : 0

Degree SM09 - 0 PV = Present Value

Reversal - 0 Axis Home Error

PV Pos 0.000

PV Save PV Save

Origin Pos 0.000

Return C/V Giving Pos 0.000

JOG

Position Velocity

C/V Width Position C/V Width Velocity

Transfer Position Transfer Velocity

Insert Part Position Insert Part Velocity

Supplier Position Supplier Velocity

Reversal Position Reversal Velocity

Data Read Home

Data Save Acc/Dec

Limit

0 / 0 / 0 Limit

0 : 0

Main Manual Monitor Data Model Alarm Ver:2307

- You can set the origin of the reversal and the position value when using the return conveyor.
- After changing, press and hold the data save button for 1 second to save.



### 3-6. Velocity Data(Model Common Data)

#### - Conveyor width velocity data

The screenshot shows the 'Velocity Data' screen for Model 000. The top bar includes 'Velocity Data', 'Model 000', and 'Base No 331'. The main display area is divided into two sections. The left section, labeled 'mm/sec', shows 'C/V -W Axis' with a 'Velocity Limit' of 0.000 and 'Model Pos' of 0.000. The right section, labeled 'mm/sec', shows 'SM01 - X' with a 'Velocity Limit' of 0.000 and 'Model Pos' of 0.000. A 'PV = Present Value' label is visible. The right sidebar contains buttons for 'Position' (C/V Width Position, Transfer Position, Insert Part Position, Supplier Position, Reversal Position) and 'Velocity' (C/V Width Velocity, Transfer Velocity, Insert Part Velocity, Supplier Velocity, Reversal Velocity). Below these are 'Home', 'Acc/Dec', and 'Limit' buttons. The bottom bar includes 'Main', 'Manual', 'Monitor', 'Data', 'Model', 'Alarm', and 'Ver:2307'.

- The velocity can be set when adjusting the conveyor width.
- After changing, press and hold the data save button for 1 second to save.

#### - Heat sink transfer velocity data

The screenshot shows the 'Velocity Data' screen for Model 000. The top bar includes 'Velocity Data', 'Model 000', and 'Base No 332'. The main display area is divided into two sections. The left section, labeled 'mm/sec', shows 'Chuck -W Axis' with a 'Velocity Limit' of 0.000 and 'Wait Pos' of 0.000. The right section, labeled 'mm/sec', shows 'Transfer -X Axis' with a 'Velocity Limit' of 0.000 and 'Wait Pos' of 0.000. A 'PV = Present Value' label is visible. The right sidebar contains buttons for 'Position' (C/V Width Position, Transfer Position, Insert Part Position, Supplier Position, Reversal Position) and 'Velocity' (C/V Width Velocity, Transfer Velocity, Insert Part Velocity, Supplier Velocity, Reversal Velocity). Below these are 'Home', 'Acc/Dec', and 'Limit' buttons. The bottom bar includes 'Main', 'Manual', 'Monitor', 'Data', 'Model', 'Alarm', and 'Ver:2307'.

- Tilting chuck width axis and heat sink transfer-You can set the velocity when moving the X axis..
- After changing, press and hold the data save button for 1 second to save.

- Holder insert velocity data

**Velocity Data**

Model: 000

Base No: 333    0 yy 0m 0d  
0 : 0

Holder Insert Unit	mm/sec		mm/sec		degree/sec		degree/sec	
	SM04 - X		SM05 - Y		SM06 - Z1		SM07 - Z2	
Velocity Limit	Home	Error	Home	Error	Home	Error	Home	Error
	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Wait Pos'	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
Insert Pos'	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000

PV = Present Value

**Position**

- C/V Width Position
- Transfer Position
- Insert Part Position
- Supplier Position
- Reversal Position

**Velocity**

- C/V Width Velocity
- Transfer Velocity
- Insert Part Velocity
- Supplier Velocity
- Reversal Velocity

**Home**

Data Read

**Acc/Dec**

Acc/Dec

**Limit**

Limit

0 / 0 / 0  
0 : 0

Main    Manual    Monitor    Data    Model    Alarm

Ver:2307

- You can set the velocity for holder insertion and movement of press-in position.
- After changing, press and hold the data save button for 1 second to save.

- Holder supply velocity data

**Velocity Data**

Model 000

Base No 334

0 yy 0m 0d  
0 : 0

**Holder Trans - 0 Axis**

SM08 - 0

Home Error

Velocity Limit 0.000

Receive Wait Pos' 0.000

Receive Pos' 0.000

Give Wait Pos' 0.000

Give Pos' 0.000

Degree/sec

PV = Present Value

**Position**

C/V Width Position

Transfer Position

Insert Part Position

Supplier Position

Reversal Position

**Velocity**

C/V Width Velocity

Transfer Velocity

Insert Part Velocity

Supplier Velocity

Reversal Velocity

**Home**

Data Read

Data Save

**Acc/Dec**

Acc/Dec

**Limit**

Limit

0 / 0 / 0  
0 : 0

Main Manual Monitor Data Model Alarm

Ver:2307

- You can set the velocity when moving the holder transfer position.
- After changing, press and hold the data save button for 1 second to save.

## - Reversal velocity data

Velocity Data		Model	000	Base No	335	0 yy 0m 0d	0 : 0
Degree/sec SM09 - $\ominus$ - H + Home Error Velocity Limit 0.000 Origin Pos' 0.000 Return C/V Giving Pos' 0.000 Rotation Pos' 0.000				PV = Present Value			
				<b>Position</b> C/V Width Position Transfer Position Insert Part Position Supplier Position Reversal Position	<b>Velocity</b> C/V Width Velocity Transfer Velocity Insert Part Velocity Supplier Velocity Reversal Velocity		
				Data Read Data Save	<b>Home</b> Home <b>Acc/Dec</b> Acc/Dec <b>Limit</b> Limit		
				0 / 0 / 0 0 : 0			
Main	Manual	Monitor	Data	Model	Alarm	Ver:2307	

- You can set the velocity when moving the reversal position.
- After changing, press and hold the data save button for 1 second to save.

### 3-7. Home



- It is possible to move the position of the sensor home of the servo.



### 3-8. Acc / Dec(Model Common Data)

<div>Acc/Dec</div>		<div>Model</div> <div>000</div>	<div>Base No</div> <div>365</div>	<div>0 yy 0m 0d</div> <div>0 : 0</div>
Model Common Data				
<div>SM01 C/V-W</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM02 Chuck-W</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM03 Trans-X</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>
<div>SM04 Insert-X</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM05 Insert-Y</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM06 Insert-Z</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>
<div>SM07 Press-Z</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM08 Holder Trans-θ</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>		<div>SM09 Reversal-θ</div> <div>Accelation 0.000 Sec</div> <div>Deceleration 0.000 Sec</div>
<div>Home</div> <div>Home</div> <div>Acc/Dec</div> <div>Acc/Dec</div> <div>Limit</div> <div>Limit</div> <div>Data Read</div> <div>Data Save</div> <div>0 / 0 / 0</div> <div>0 : 0</div>				
Main	Manual	Monitor	Data	Model
				Alarm
Ver:2307				

- Servo acceleration and deceleration can be set.
- After changing, press and hold the data save button for 1 second to save.



### 3-9. Limit(Model Common Data)

Limit

Model 000

Base No 369

0 yy 0m 0d  
0 : 0

Model Common Data

Servo Number	Motor Name	-LIMIT	+LIMIT
SM01	C/V-W	0.000	0.000
SM02	Chuck-W	0.000	0.000
SM03	Trans-X	0.000	0.000
SM04	Insert-X	0.000	0.000
SM05	Insert-Y	0.000	0.000
SM06	Insert-Z	0.000	0.000
SM07	Press-Z	0.000	0.000
SM08	Holder Trans-θ	0.000	0.000
SM09	Reversal-θ	0.000	0.000

Unit:mm

Home

Home

Acc/Dec

Acc/Dec

Limit

Limit

Data Read

Data Save

0 / 0 / 0  
0 : 0

Main

Manual

Monitor

Data

Model

Alarm

Ver:2307

- You can set servo soft limit.
- An alarm occurs when the teaching value is out of the limit.
- After changing, press and hold the data save button for 1 second to save.

### 3-10. Servo Power

Servo Power		Model	000	Base No 381		0 yy 0m 0d 0 : 0	
SM01 C/V-W		SM02 Chuck-W		SM03 Trans-X		SM04 Insert-X	
ON	OFF	ON	OFF	ON	OFF	ON	OFF
SM05 Insert-Y		SM06 Insert-Z		SM07 Press-Z		SM08 Holder Trans-ø	
ON	OFF	ON	OFF	ON	OFF	ON	OFF
SM09 Reversal-ø							
ON	OFF						
						Servo All	
						ON	OFF
Main	Manual	Monitor	Data	Model	Alarm	Ver:2307	

- Servo power can be turned ON/OFF.

### 3-11. Load Factor

Load Factor

Model 000

Base No 385

0 yy 0m 0d  
0 : 0

Servo Number	Motor Name	PV	Alarm Set Value		Pick Value	Alarm Set Value	
SM01	C/V-W	0	0		0	0	
SM02	Chuck-W	0	0		0	0	
SM03	Trans-X	0	0		0	0	
SM04	Insert-X	0	0		0	0	
SM05	Insert-Y	0	0		0	0	
SM06	Insert-Z	0	0		0	0	
SM07	Press-Z	0	0		0	0	
SM08	Holder Trans-θ	0	0		0	0	
SM09	Reversal-θ	0	0		0	0	

Data Read

Data Save

0 / 0 / 0  
0 : 0

Main

Manual

Monitor

Data

Model

Alarm

Ver:2307

■ Servo load factor can be set..

### 3-12. Use / Unuse



- You can use / unuse the function of the equipment.

### 3-13. Delay Time (Model Common Data)

Delay Time		Model	000	Base No	395	0 yy 0m 0d 0 : 0
Model Common Data						
Align Cylinder Up Delay	0.0 Sec	Reversal Product Output Complete Delay	0.0 Sec	<div>Data Read</div> <div>Data Save</div> <div>0 / 0 / 0 0 : 0</div>		
Bowl Feeder Run Delay	0.0 Sec	Return Conveyor Arrive Sensor On Delay	0.0 Sec			
Bowl Feeder Stop Delay	0.0 Sec	Return C/V Stop Delay for Cycle End	0.0 Sec			
Bowl Feeder Shortage Warning Delay	0.0 Sec	—	0.0 Sec			
Linear Feeder Run Delay	0.0 Sec	—	0.0 Sec			
Linear Feeder Stop Delay	0.0 Sec	—	0.0 Sec			
Linear Feeder Shortage Warning Delay	0.0 Sec	—	0.0 Sec			
Insert Unit Insert Complete Delay	0.0 Sec	—	0.0 Sec			
Insert Unit Press Complete Delay	0.0 Sec	—	0.0 Sec			
Insert Unit Holder Shoot Stop Delay	0.0 Sec	—	0.0 Sec			
				<div>Main</div> <div>Manual</div> <div>Monitor</div> <div>Data</div> <div>Model</div> <div>Alarm</div> <div>Ver:2307</div>		

- Function and sensor delay time can be set.
- After changing, press and hold the data save button for 1 second to save.



3-14. Model

Model

Model000

Base No401

0yy0m0d  
0:0

NO	Model Name	NO	Model Name
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0
000	0 / 0 / 0 0 : 0	000	0 / 0 / 0 0 : 0

Select Screen

Model Name Change

Model Delete

Model Copy

Model Read

Model 1-20

Model 21-40

Model 41-60

Model 61-80

Model 81-100

MainManualMonitorDataModelAlarm

Ver:2307

Model Name Change

Model Number000

Select Model Name

To be Changed Model Name

!! Precautions !!  
Run after the facility is completely shut down before the operation.

Save

Model Delete

Model Number000

Select Model Name

!! Precautions !!  
Run after the facility is completely shut down before the operation.

Delete

Model Copy

Model NumberSelect Number000

Copy Number000

Select Model Name

To be Changed Model Name

!! Precautions !!  
Run after the facility is completely shut down before the operation.

Model Copy

Model Read

Present Model000

Change Model000

Present Model Name

Change Model Name

!! Precautions !!  
Run after the facility is completely shut down before the operation.

Read


■ You can change the model name, delete, copy, load.

### 3-15. Alarm

The screenshot shows a control interface for an alarm system. At the top, there is a header bar with several fields: a blue 'Alarm' button, a 'Model' field with the value '000', a 'Base No' field with the value '601', and a date/time field showing '0 yy 0m 0d' and '0 : 0'. Below the header is a large black area for the alarm message. At the bottom of this area, there is a status bar with three indicators: a red square for 'Alarm', a blue square for 'Confirm', and a yellow square for 'Restore'. Below the status bar is a row of buttons: 'Select', 'Up Arrow', 'Down Arrow', 'Next Page', 'Reset' (highlighted with a red border), 'Buzzer Stop' (highlighted with a green border), 'Alarm', 'Alarm History', and 'Servo NG Code'. At the very bottom, there is a navigation bar with buttons for 'Main', 'Manual', 'Monitor', 'Data', 'Model', and 'Alarm', followed by the version number 'Ver:2307'.

- When an alarm occurs, you can check the content and time.
- Occur Date: Displays the alarm occurrence date
- Occur time: Displays the alarm occurrence time
- Message: Indicates the content of the alarm occurrence
- End time: Displays the alarm clear time

### 3-16. Emergency Stop Screen




- Displays equipment emergency stop status.


#### ■ EMO Switch design

Emergency stop (EMO) switch has the following functions and features.


- Emergency stop (EMO) circuit is an independent circuit.
- When the emergency stop (EMO) switch is pressed, power is cut off from the AC220V (voltage varies depending on specifications) power line.
- When the emergency stop (EMO) switch is pressed, the contact of the electromagnetic switch opens. Opening of the electromagnetic switch contacts cuts off the entire power supply.
- To recover from emergency stop (EMO) status, turn the Key EMO switch clockwise to reset. This recovery enables a system power restart.


#### ■ Recovery from EMO

**DANGER**



Before restoring your system from EMO, make sure no one is using it. Also make sure that there are no tools or foreign objects inside the system and that the system works properly when powered on.

**DANGER**



Only trained personnel can recover systems from EMO. Customers should be fully aware of anyone working with or near the system and should establish their own safe work procedures regarding recovery from EMO.



### 3-17. Signal Tower

- 3 phase Signal Tower(Red, Yellow, Green, Buzzer:DC24V LED)

-.. Display color and equipment status

Equipment status	Red	Yellow	Green	Buzzer
Before operating , manual	○			X
Ready for operation, in complete stop			△	X
In automatic operation			○	X
When an error occurs	△			Intermittent sound
Emergency stop	○			○

Note) ○: Lighting, △: Flickering




- ← Red
- ← Yellow
- ← Green

### 3-18. Door Interlock Switch Description And Location

- D40A-1C2 : Small Contactless Door Switch


- G9SX-NSA222-T03 : Contactless Door Switch For Controller



### 3-19. Safety Procedures For Invalidation Door Interlock Switches


1. Reset Button Click when All Power is ON → Safety Control Normalize

(Condition: Emergency S/W release of equipment and Door S/W (8 locations) must be ON.)




< INTERLOCK Normal >

2. When Drive Key S/W Auto ON, Start Button is clicked, the equipment operates normally, and when the door is opened or emergency S/W is operated, the equipment turns off and stops.
3. When Drive Key S/W Manual ON, Stop Button is clicked, the equipment is normally stopped, The door interlock is invalidated, so the operator can open the door for necessary work. Safety interlock operation turns off at the same time door is opened.



< Safety Interlock operation turns off >

4. After all work is completed, the operator closes all doors,  
The Safety Interlock must be normalized by pressing the Reset Button.



< Safety Interlock normalized >

## 3-20. Tag out

When performing maintenance service, the main switch must be turned off.

At this time, the main switch is locked to prevent other operators from carelessly touching it.

Also, tags are installed to alert other employees. This is tag out.

At least the following sections of equipment require tagout.

### ■ Main switch

In addition, during service maintenance work in the utility zone side or internal loading area,

A tag is also required to install the other side of the machine (front).


#### - Power supply tag out

The main switch is locked in the main switch OFF position.

To warn other operators not to touch the main switch after locking

Install the tag above the main switch.

#### ① Locking the circuit breaker



**Feature 3 Breaker lock**

#### ② There is a tag on the circuit breaker.



### 3-20-1. LOTO (Log out / Tag out) Procedure

#### **DANGER**



Persons performing servicing of this system should be aware of the importance of lockout and learn all lockout procedures described in this section prior to servicing.

#### **WARNING**



When more than one person performs a service at the same time, designate everyone supervising as a “manager”. Managers must always be aware of the work status and implement lockout procedures.

#### **WARNING**



If the system is still running, perform a shutdown procedure and ensure the system is completely stopped before locking.

#### **WARNING**





Each employee must attach a separate tag announcing the owner's location and name prior to service by one or more team members.

## 3-21. System Precautions


### 3-21-1. Caution On High-Voltage Part


While the high-voltage live parts of the system are protected by panels and guards, the following precautions must be observed to prevent accidents.

**DANGER**



- Do not remove the panel or door that has the high voltage live part warning label and label attached without permission, or do not operate the removed panel/door or system.  
Also, do not open any covers unless you are authorized to do so.
- Under no circumstance, do not touch live parts until thoroughly inspected.
- Always cut off the main power before opening any guards as a cover of necessity during operation.
- Do not operate metal objects including watches and rings while working. Otherwise, accidents may occur due to unintentional/indirect contact.
- Before starting work, check all related electrical wiring and that there are no live parts within the scope of work. If necessary, lock out upstream of the main breaker main side (where the hazard warning label is attached to the cover), since this side is alive even after the main breaker switch is set to OFF.
- Do not place any removed parts (screws, etc.) or tools on the system during operation.  
If these objects fall inside or otherwise affect the circuitry, a short circuit may occur.

**DANGER**





Before servicing any system that does not require electricity, shut off the system power according to the procedures mentioned after.

## 4. Electric Drawing

[illegible]



NO.	NAME	DESCRIPTION	DESCRIPTION	UNIT	QTY
1	W	FRONT PANEL	FRONT PANEL	PIECE	1-PC
2	W/B	HEAT SINK HOLDER (P-1)	HEAT SINK	NO. PART	1-PC
3	W/B	HEAT SINK HOLDER (P-2)	HEAT SINK	NO. PART	1-PC
4	W/B	HEAT SINK HOLDER (P-3)	HEAT SINK	NO. PART	1-PC
5	W/B	HEAT SINK HOLDER (P-4)	HEAT SINK	NO. PART	1-PC
6	W/B	HEAT SINK HOLDER (P-5)	HEAT SINK	NO. PART	1-PC
7	T/L	TOUCH PANEL	TOUCH PANEL	2-139T	1-PC
8	-	-	-	-	-
9	-	-	-	-	-
10	-	-	-	-	-



<FRONT VIEW of CABINET>


TOUCH PANEL

DESIGN	CHECK	APPROVAL	PROJECT	HEAT SINK HOLDER INSERTER	DWG. NAME	TOUCH PANEL VIEW	DWG. NO	HOLDIN-000	002
S.S. Jeon	S.S. Jeon	S.S. Jeon					DATE	2023.06.	003




\* SYMMETRY PANEL \*


\* MATERIAL LIST \*



<FRONT VIEW of CABINET>



<INNER VIEW of CABINET>



<BOTTOM VIEW of CABINET>

NO.	ITEM	DESCRIPTION	QTY	UNIT
1	1.1	1.1.1	1.1.1.1	1.1.1.2
2	2.1	2.1.1	2.1.1.1	2.1.1.2
3	3.1	3.1.1	3.1.1.1	3.1.1.2
4	4.1	4.1.1	4.1.1.1	4.1.1.2
5	5.1	5.1.1	5.1.1.1	5.1.1.2
6	6.1	6.1.1	6.1.1.1	6.1.1.2
7	7.1	7.1.1	7.1.1.1	7.1.1.2
8	8.1	8.1.1	8.1.1.1	8.1.1.2
9	9.1	9.1.1	9.1.1.1	9.1.1.2
10	10.1	10.1.1	10.1.1.1	10.1.1.2
11	11.1	11.1.1	11.1.1.1	11.1.1.2
12	12.1	12.1.1	12.1.1.1	12.1.1.2
13	13.1	13.1.1	13.1.1.1	13.1.1.2
14	14.1	14.1.1	14.1.1.1	14.1.1.2
15	15.1	15.1.1	15.1.1.1	15.1.1.2
16	16.1	16.1.1	16.1.1.1	16.1.1.2
17	17.1	17.1.1	17.1.1.1	17.1.1.2
18	18.1	18.1.1	18.1.1.1	18.1.1.2
19	19.1	19.1.1	19.1.1.1	19.1.1.2
20	20.1	20.1.1	20.1.1.1	20.1.1.2
21	21.1	21.1.1	21.1.1.1	21.1.1.2
22	22.1	22.1.1	22.1.1.1	22.1.1.2
23	23.1	23.1.1	23.1.1.1	23.1.1.2
24	24.1	24.1.1	24.1.1.1	24.1.1.2
25	25.1	25.1.1	25.1.1.1	25.1.1.2
26	26.1	26.1.1	26.1.1.1	26.1.1.2
27	27.1	27.1.1	27.1.1.1	27.1.1.2
28	28.1	28.1.1	28.1.1.1	28.1.1.2
29	29.1	29.1.1	29.1.1.1	29.1.1.2
30	30.1	30.1.1	30.1.1.1	30.1.1.2
31	31.1	31.1.1	31.1.1.1	31.1.1.2
32	32.1	32.1.1	32.1.1.1	32.1.1.2
33	33.1	33.1.1	33.1.1.1	33.1.1.2
34	34.1	34.1.1	34.1.1.1	34.1.1.2
35	35.1	35.1.1	35.1.1.1	35.1.1.2
36	36.1	36.1.1	36.1.1.1	36.1.1.2
37	37.1	37.1.1	37.1.1.1	37.1.1.2
38	38.1	38.1.1	38.1.1.1	38.1.1.2
39	39.1	39.1.1	39.1.1.1	39.1.1.2
40	40.1	40.1.1	40.1.1.1	40.1.1.2
41	41.1	41.1.1	41.1.1.1	41.1.1.2
42	42.1	42.1.1	42.1.1.1	42.1.1.2
43	43.1	43.1.1	43.1.1.1	43.1.1.2
44	44.1	44.1.1	44.1.1.1	44.1.1.2
45	45.1	45.1.1	45.1.1.1	45.1.1.2
46	46.1	46.1.1	46.1.1.1	46.1.1.2
47	47.1	47.1.1	47.1.1.1	47.1.1.2
48	48.1	48.1.1	48.1.1.1	48.1.1.2
49	49.1	49.1.1	49.1.1.1	49.1.1.2
50	50.1	50.1.1	50.1.1.1	50.1.1.2
51	51.1	51.1.1	51.1.1.1	51.1.1.2
52	52.1	52.1.1	52.1.1.1	52.1.1.2
53	53.1	53.1.1	53.1.1.1	53.1.1.2
54	54.1	54.1.1	54.1.1.1	54.1.1.2
55	55.1	55.1.1	55.1.1.1	55.1.1.2
56	56.1	56.1.1	56.1.1.1	56.1.1.2
57	57.1	57.1.1	57.1.1.1	57.1.1.2
58	58.1	58.1.1	58.1.1.1	58.1.1.2
59	59.1	59.1.1	59.1.1.1	59.1.1.2
60	60.1	60.1.1	60.1.1.1	60.1.1.2
61	61.1	61.1.1	61.1.1.1	61.1.1.2
62	62.1	62.1.1	62.1.1.1	62.1.1.2
63	63.1	63.1.1	63.1.1.1	63.1.1.2
64	64.1	64.1.1	64.1.1.1	64.1.1.2
65	65.1	65.1.1	65.1.1.1	65.1.1.2
66	66.1	66.1.1	66.1.1.1	66.1.1.2
67	67.1	67.1.1	67.1.1.1	67.1.1.2
68	68.1	68.1.1	68.1.1.1	68.1.1.2
69	69.1	69.1.1	69.1.1.1	69.1.1.2
70	70.1	70.1.1	70.1.1.1	70.1.1.2
71	71.1	71.1.1	71.1.1.1	71.1.1.2
72	72.1	72.1.1	72.1.1.1	72.1.1.2
73	73.1	73.1.1	73.1.1.1	73.1.1.2
74	74.1	74.1.1	74.1.1.1	74.1.1.2
75	75.1	75.1.1	75.1.1.1	75.1.1.2
76	76.1	76.1.1	76.1.1.1	76.1.1.2
77	77.1	77.1.1	77.1.1.1	77.1.1.2
78	78.1	78.1.1	78.1.1.1	78.1.1.2
79	79.1	79.1.1	79.1.1.1	79.1.1.2
80	80.1	80.1.1	80.1.1.1	80.1.1.2
81	81.1	81.1.1	81.1.1.1	81.1.1.2
82	82.1	82.1.1	82.1.1.1	82.1.1.2
83	83.1	83.1.1	83.1.1.1	83.1.1.2
84	84.1	84.1.1	84.1.1.1	84.1.1.2


MAIN PANEL

DESIGN	CHECK	APPROVAL	PROJECT	HEATSINK HOLDER	DWG. NAME	MAIN PANEL	DWG. NO	HOLDIN-000	003
holder insert	M/S.S. Jeon	S.S. Jeon	S.S. Jeon	INSERTER	INNER VIEW	DATE	2023. 06.		003

# HeatSink Holder Inserter Electric Drawing

2023-06-30


		DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	COVER SHEET	DWG. NO DATE	HOLDING NO 2023.06.	000 / 000
		S.S. Jeon	S.S. Jeon	S.S. Jeon	HEATSINK HOLDER INSERTER					




DESIGN	CHECK	APPROVAL	PROJECT	DWG.	MAIN POWER	DWG. NO	HOLDIN-000	001	023
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	NAME	2Ø 220V/AC	DATE	2023. 06.		

POWER CIRCUIT





	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y
01	Control Power 2Phase DC 24V (M03-18V)																								
02																				Control Power 2Phase DC 24V (M03-17V)					
03																									
04																									
05																									
06																									
07																									
08																									
09																									
10																									
11																									
12																									
13																									
14																									
15																									
16																									
17																									
18																									
19																									
20																									
21																									
22																									
23																									
24																									
25																									
26																									
27																									
28																									
29																									
30																									
31																									
32																									
33																									
34																									









## SFC01

### CONTROL CIRCUIT

065X-NSA222-T03



(M003-26U)



N24 →

AWG #18, OR

SF01 SAFETY CIRCUIT

[illegible]

Door Safety\_SF2\_(Local Door Sensor)





DOOR SAFETY CIRCUIT

DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	EMO/DOOR SAFETY CIRCUIT	DWG. NO	HOLDIN-000	011 / 040
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER			DATE	2023.06.	

EMO Safety\_SF1\_(Local Emergency Switch)


### Safety Control Power Diagram



### EMO SAFETY CIRCUIT


[illegible]

Input Conveyor Width Adjustment




DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	SERVO MOTOR POWER	DWG. NO	HOLDIN -000	007
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	20 220VAC	DATE	2023. 05.	023	

Transfer Chuck Width Adjustment



DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	SERVO MOTOR POWER	DWG. NO	HOLDIN-000	008
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	20 220VAC	DATE	2023. 06.	023	

# Transfer Servo




DESIGN S.S.Jeon CHECK S.S.Jeon APPROVAL S.S.Jeon PROJECT HEATSINK HOLDER INSERTER DWG. NAME SERVO MOTOR POWER 20 220VAC DWG. NO DATE HOLDIN-000 009 023

SERVO MOTOR CIRCUIT




Insert Y-AXIS Servo



DESIGN	CHECK	APPROVAL	PROJECT	HEATSINK HOLDER	DWG. NAME	SERVO MOTOR POWER	DWG. NO	HOLDIN-000	011
S.S.Jeon	S.S.Jeon	S.S.Jeon	INSERTER		20 220VAC		DATE	2023. 06.	023



## Insert Z-AXIS Servo




PIN NO.	COLOR	NAME
10	검	P24
3	흑	N24
2	적	FLS
12	등	RLS
19	황	DOG
20	녹	EM2
13	청	MBR

SERVO MOTOR CIRCUIT

[illegible]


A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---



PIN NO.	COLOR	NAME
10	갈	P24
3	흑	N24
2	적	FLS
12	등	RLS
19	황	DOG
20	녹	EM2
13	청	MBR


## SERVO MOTOR CIRCUIT

Holder Transfer Servo




DESIGN	CHECK	APPROVAL	PROJECT	DWG. NO	SERVO MOTOR POWER	DATE	HOLDIN-000	014
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	NAME	20 220V/AC	2023. 06.	023	

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	+
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---




PIN NO.	COLOR	NAME
10	갈	P24
3	흑	N24
2	적	FLS
12	동	RLS
19	황	D0G
20	녹	EM2
13	청	MBR

Input Conveyor AC SPG Motor(Left)




# Input Conveyor AC SPG Motor (Right)



DESIGN	CHECK	APPROVAL	PROJECT	HEATSINK HOLDER	SPG MOTOR	DWG. NO	HOLDIN-000	017
S.S.Jeon	S.S.Jeon	S.S.Jeon	INSERTER	NAME	POWER 20 220V/AC	DATE	2023. 06.	023

AC SPG MOTOR CIRCUIT


# Return Conveyor AC SPG Motor



DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	SPG MOTOR POWER	DWG. NO	HOLDIN-000	018	023
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	20 220V/AC	DATE	2023.06.			

AC SPG MOTOR CIRCUIT

# Output Conveyor AC SPG Motor




DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	SPG MOTOR POWER	DWG. NO	HOLDIN-000	019
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	20 220VAC	DATE	2023.06.	023	



## Reverse Part Upper Conveyor


## BLC-16



DESIGN	CHECK	APPROVAL	PROJECT	BUDC MOTOR POWER	DMG. NO	HOLDIN-000	020
S.S. Jeon	S.S. Jeon	S.S. Jeon	HEATSINK HOLDER INSERTER	2Ø 220V/AC	DATE	2023. 06.	023


## Reverse Part Bottom Conveyor

## BLC-16




	CHECK	DESIGN	PROJECT	BLDG MOTOR POWER 20 220VAC	DWG. NO DATE	HOLDIN-000 / 021 023 ♣
♠	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER	NAME	2023. 06.	



Color Sensor(C84-P3612)




## Bowl Feeder & Linear Feeder



## Bowl Feeder



## Linear Feeder

[illegible]

01	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y
02	(M003-2BU)																								
03																									
04																									
05																									
06																									
07																									
08																									
09																									
10																									
11																									
12																									
13																									
14																									
15																									
16																									
17																									
18																									
19																									
20																									
21																									
22																									
23																									
24																									
25																									
26																									
27																									
28																									
29																									
30																									
31																									
32																									
33																									
34																									
35																									
36																									
37																									
38																									
39																									
40																									
41																									
42																									
43																									
44																									
45																									
46																									
47																									
48																									
49																									
50																									
51																									

INPUT CARD		OD77MS16	
SLOT No.		00	
Pin No.	Address		
φ00	B20	X000	
φ01	B19	X001	
φ02	B18	X002	
φ03	B17	X003	
φ04	B16	X004	
φ05	B15	X005	
φ06	B14	X006	
φ07	B13	X007	
φ08	B12	X008	
φ09	B11	X009	
φ0A	B10	X00A	
φ0B	B09	X00B	
φ0C	B08	X00C	
φ0D	B07	X00D	
φ0E	B06	X00E	
φ0F	B05	X00F	
	B04	NC	
	B03	NC	
	B02	COIL ( +24V )	
φ +V	B01	COIL ( +24V )	

INPUT CARD		OD77MS16	
SLOT No.		00	
Pin No.	Address	DESCRIPTION	
φ10	A20	X010	
φ11	A19	X011	
φ12	A18	X012	
φ13	A17	X013	
φ14	A16	X014	
φ15	A15	X015	
φ16	A14	X016	
φ17	A13	X017	
φ18	A12	X018	
φ19	A11	X019	
φ1A	A10	X01A	
φ1B	A09	X01B	
φ1C	A08	X01C	
φ1D	A07	X01D	
φ1E	A06	X01E	
φ1F	A05	X01F	
	A04	NC	
	A03	NC	
	A02	NC	
φ0V	A01	NC	

DESIGN				CHECK		APPROVAL		PROJECT		HEATSINK HOLDER		DWG. NAME		RTBOT INPUT		CIRCUIT		DWG. NO		HOLDIN-000		001	
S.S.Jeon				S.S.Jeon		S.S.Jeon		HEATSETER		INSERTEH				CIRCUIT				DATE		2023.06.		005	

X000~X01F

51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----



[illegible]

(MOD-28U)

01	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	51
02																										52
03																										53
04	INPUT CARD		QV41P																						54	
05	SLOT No.		02																						55	
06	DESCRIPTION		ADDRESS		PIN No.																				56	
07	OP PAIR, START LAMP		Y080		R1																				57	
08	OP PAIR, STOP PAIR, LAMP		Y081		R2																				58	
09	OP PAIR, RESET LAMP		Y082		R3																				59	
10	-		Y083		R4																				60	
11	-		Y084		R5																				61	
12	TOWER LAMP (RED)		Y085		R6																				62	
13	TOWER LAMP (YELLOW)		Y086		R7																				63	
14	TOWER LAMP (GREEN)		Y087		R8																				64	
15	-		Y088		R9																				65	
16	TOWER LAMP (BLUE)		Y089		R10																				66	
17	-		Y090		R11																				67	
18	INPUT CIV SEPARATE CIV, FORWARD SOL		Y091		R10																				68	
19	INPUT CIV 1ST STOPPER DOWN SOL		Y094		R11																				69	
20	INPUT CIV 2ND STOPPER DOWN SOL		Y095		R12																				70	
21	-		Y096		R13																				71	
22	TOWER PART CHUCK TILT FORWARD SOL		Y090		R14																				72	
23	TOWER PART CHUCK TILT FORWARD SOL		Y091		R15																				73	
24	INPUT CIV ALIGHT UP SOL		Y08F		R16																				74	
25	-		Y08F		R16																				75	
26	-		Y08F		R16																				76	
27	-		Y08F		R16																				77	
28	-		Y08F		R16																				78	
29	-		Y08F		R16																				79	
30	-		Y08F		R16																				80	

01	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	51
02																										52
03																										53
04	INPUT CARD		QV41P																						54	
05	SLOT No.		02																						55	
06	DESCRIPTION		ADDRESS		PIN No.																				56	
07	OP PAIR, START LAMP		Y080		R1																				57	
08	OP PAIR, STOP PAIR, LAMP		Y081		R2																				58	
09	OP PAIR, RESET LAMP		Y082		R3																				59	
10	-		Y083		R4																				60	
11	-		Y084		R5																				61	
12	TOWER LAMP (RED)		Y085		R6																				62	
13	TOWER LAMP (YELLOW)		Y086		R7																				63	
14	TOWER LAMP (GREEN)		Y087		R8																				64	
15	-		Y088		R9																				65	
16	TOWER LAMP (BLUE)		Y089		R10																				66	
17	-		Y090		R11																				67	
18	INPUT CIV SEPARATE CIV, FORWARD SOL		Y091		R10																				68	
19	INPUT CIV 1ST STOPPER DOWN SOL		Y094		R11																				69	
20	INPUT CIV 2ND STOPPER DOWN SOL		Y095		R12																				70	
21	-		Y096		R13																				71	
22	TOWER PART CHUCK TILT FORWARD SOL		Y090		R14																				72	
23	TOWER PART CHUCK TILT FORWARD SOL		Y091		R15																				73	
24	INPUT CIV ALIGHT UP SOL		Y08F		R16																				74	
25	-		Y08F		R16																				75	
26	-		Y08F		R16																				76	
27	-		Y08F		R16																				77	
28	-		Y08F		R16																				78	
29	-		Y08F		R16																				79	
30	-		Y08F		R16																				80	


Y080-Y07F

DESIGN	CHECK	APPROVAL	PROJECT	DWG. NAME	OUTPUT	DWG. NO	HOLDIN-000	004	005
S.S.Jeon	S.S.Jeon	S.S.Jeon	HEATSINK HOLDER INSERTER		CIRCUIT	DATE	2023.06.		



[illegible]

Y080~Y09F



## 5. ELECTRIC PART LIST

ASSEMBLY	Line	도면번호	부품번호	작품 용칭	수량	종수	규격	제조사
			CIRCUIT	TYPE OF COMPONENT			COMPONENT TYPE NO.	MANUFACTURER
HEATSINK HOLDER INSERTER	2	HOLDIN-000	1	ELCB01	1	2	ABS-33c/20A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	2	POWER LAMP	1	2	KGP-HD2W(WHITEAC220V)	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	3	MCCB-01/MCCB-02	2	4	ABS32c-10A/ABS32c-15A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	4	Power Block	2	4	SPS45-M8/12xM4	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	5	Magnet	2	4	MC-22B-DC24V	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	6	MCCB	2	4	MMS (32S-1.0-1.6A)	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	7	MCCB	5	10	MMS (32S-0.63-1.0A)	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	8	MCCB	2	4	MMS (32S-1.6-2.5A)	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	9	POWER SUPPLY	1	2	SPB-180-247.5A	AUTONICS
HEATSINK HOLDER INSERTER	2	HOLDIN-000	10	POWER SUPPLY	1	2	SPB-060-242.5A	AUTONICS
HEATSINK HOLDER INSERTER	2	HOLDIN-000	11	Ethernet Hub	1	2	EDS-205	MOXA
HEATSINK HOLDER INSERTER	2	HOLDIN-000	12	Novae Fiber	1	2	WFS06TD	WOONYOUNG
HEATSINK HOLDER INSERTER	2	HOLDIN-000	13	POWER Module	1	2	Q61P	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	14	Base Module	1	2	Q35B	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	15	Cpu Module	1	2	Q03UDVCPU	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	16	Positioning Module	1	2	Q077MS16	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	17	input Module	1	2	QX42	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	18	Output Module	1	2	QY40P	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	19	Circuit Protector	2	4	BK6H-2P-1A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	20	Circuit Protector(ELB)	1	2	32GR-2P-15A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	21	Circuit Protector	4	8	BK6H-2P-6A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	22	Circuit Protector	1	2	BK6H-2P-10A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	23	Circuit Protector	1	2	BK6H-2P-3A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	24	Circuit Protector	2	4	BK6H-1P-6A,3A	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	25	SPG MOTOR CONTROLLER	4	8	SIX02CE	SPG MOTOR
HEATSINK HOLDER INSERTER	2	HOLDIN-000	26	Thermostat	1	2	RTM-50P	ILUN ELECTRIC
HEATSINK HOLDER INSERTER	2	HOLDIN-000	27	DRIVE AMP	5	10	MR-E-10B	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	28	DRIVE AMP	2	4	MR-E-20B	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	29	DRIVE AMP	2	4	MR-E-40B	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	31	ENCORDER CABLE	9	18	MR-3ENCBL10M-A1-L	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	32	POWER CABLE	9	18	MR-PWS10BL10M-A1-L	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	33	BRAKE CABLE	2	4	MR-BKS10BL10M-A1-L	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	34	BATTERY(U)	9	18	MR-BAT6V1SET	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	35	BUS CABLE	8	16	MR-3BUS05M(0.5M)	Mitsubishi Electric
HEATSINK HOLDER INSERTER	2	HOLDIN-000	37	Servo Noise Filter	1	2	WVF-S20T1-AD	WOONYOUNG
HEATSINK HOLDER INSERTER	2	HOLDIN-000	38	RELAY	4	8	MY2N-DC24V	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	39	Terminal Relay	2	4	RT-16P-S-DC24V	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	40	MCCB	6	12	MMS (32S-0.63-1.0A)	LS Industrial System
HEATSINK HOLDER INSERTER	2	HOLDIN-000	41	SPG MOTOR SOCKET	4	8	KH-RS-11	KOINO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	42	RELAY	4	8	MY2N-DC24V	HONEYWELL
HEATSINK HOLDER INSERTER	2	HOLDIN-000	43	Terminal Relay	2	4	RT-16P-S-DC24V	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	44	ComCont	1	2	DR-220V-16A,1POLE	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	45	TERMINAL BLOCK	1	2	KH-6030-3P	KOINO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	46	INPUT BOARD	2	4	XTB-40H	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	47	OUTPUT BOARD	2	4	XTB-40H	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	48	TERMINAL BLOCK	300	600	15A	DONG-A
HEATSINK HOLDER INSERTER	2	HOLDIN-000	49	GROUND BAR	1	2	SG-EB3-30P	SEGBIZ
HEATSINK HOLDER INSERTER	2	HOLDIN-000	50	PANEL FAN	1	2	SH229HA2S(220V)	SUNTRONICS
HEATSINK HOLDER INSERTER	2	HOLDIN-000	51	FAN COVER	2	4	KFC-200	KEM
HEATSINK HOLDER INSERTER	2	HOLDIN-000	53	PILOT LAMP	1	2	KGP-HD2W	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	54	LAMP PUSH BUTTON SWITCH	1	2	KGX-HMD21B	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	55	SELECHT KEY SWITCH(2POLE/1X)	2	4	KGX-HM1A	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	56	EMO EMERGENCY SWITCH	3	6	K22-01R-EMO-1x2b	KACON
HEATSINK HOLDER INSERTER	2	HOLDIN-000	57	EMO EMERGENCY COVER	3	6	KEG82	KACON
HEATSINK HOLDER INSERTER	2	HOLDIN-000	58	LAMP PUSH BUTTON SWITCH	1	2	KGX-HMD21G	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	59	LAMP PUSH BUTTON SWITCH	1	2	KGX-HMD21R	KG AUTO
HEATSINK HOLDER INSERTER	2	HOLDIN-000	61	TOWER LAMP	1	2	ST4BL-BZ-3-24-RAG-S218	Q-LIGHT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	62	COM TB TERMINAL	1	2	XTB-COM20B	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	63	I/O LINK CABLE	4	8	C40HF-109X-1	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	64	FUSE HOLDER	1	2	1A	HANYOUNG
HEATSINK HOLDER INSERTER	2	HOLDIN-000	65	Safety Controllers	1	2	GRSX-NSA222-T03	OMRON
HEATSINK HOLDER INSERTER	2	HOLDIN-000	66	Safety Controllers	1	2	GRSX-BC202-RT	OMRON
HEATSINK HOLDER INSERTER	2	HOLDIN-000	67	Safety Relay	4	8	SFS2-DC24	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	68	Safety Relay Socket	4	8	SFS2-SW-024	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	69	Safety Relay	2	4	SFS4-DC24	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	70	Safety Relay Socket	2	4	SFS4-SW-024	SAMWON ACT
HEATSINK HOLDER INSERTER	2	HOLDIN-000	71	PVC DUCT	7	14	H60 * W80	YOUNGSIN
HEATSINK HOLDER INSERTER	2	HOLDIN-000	72	PVC DUCT	3	6	H40 * W80	YOUNGSIN
HEATSINK HOLDER INSERTER	2	HOLDIN-000	73	COM TB TERMINAL	1	2	XTB-COM40B	SAMWON ACT

**6. ELECTRIC Parts Catalog(Attached)**